

Reference

- supports parallel processing

Content

| | |
|------------------|----|
| 1 Reference..... | 2 |
| 2 History..... | 10 |

1 Reference

| Input | Unit | Description |
|-------------------------|---------------------|--|
| title 'name' | string | 'name' is a string (max. 64 characters) that is stored on the result file and appears in the header of the plots |
| >>global | | main keyword for the definition of default values holding for all models |
| kst r | m ^{1/3} /s | global Strickler value (default=30) |
| n r | SI | default Manning's n value |
| ks r | m | equivalent sand roughness diameter |
| damping_on | | considers reduction of turbulent shear forces for small flow depths (Bezzola 2002) in combination with logarithmic friction law (sand roughness ks). |
| label 'xx' r | string | name of a label (max. 4 characters) to which the Strickler-value r is related |
| hdry r | m | minimum flow depth where flow equations are being solved (for 2D model, default=0.01 m) |
| adry r | m ² | minimum wetted area of cross-section where flow equations are being solved (for 1D model, default=0.1 m ²) |
| slot_width r | m | width of (Preissmann-) slot used for calculation of pressurised flows (see option >>branch/closed) (default=0.1 m) |
| unit 'name' | string | Defines unit of input data. Possible units are: - 'minutes' for time given in minutes (instead of hour) |
| date 'mddhh' | string | real time of start of simulation (mm=month, dd=day, hh=hour) |
| yield_stress | N/m ² | yield stress for debris flow calculations (default = 0) |
| friction_slope | - | Tangens of internal friction angle $\tan \delta$ for debris flow calculations (default = 0) with viscous stress $\tau_y = \rho g h \tan \delta$. . Note: If both yield stress and friction slope are defined, the sum of the two values is taken. |
| bingham_viscosity | Pa s | Bingham viscosity μ_B for debris flow calculations (default = 0) with Bingham shear stress $\tau_B = \frac{3\mu_B q}{h^2}$. Note: If both turbulent friction (n, kst, or ks) and bingham viscosity is defined, the maximum of the two resulting stress values is taken. |
| roughness_factor | - | factor to estimate roughness diameter from mean grain-size <i>parameters for integration of 1D models</i> |
| seam_radius r | m | maximum distance from section-midpoints to cell-boundaries (of 2D mesh) where a seam (flow) can exist (used for connecting different flow models) (default = 10 m) |
| weir_coefficient | - | Poleni coefficient for calculation of fluxes between 1D and 2D models (default = 0.60) |
| >>sediment | | <i>parameters for mobile bed calculation</i> |
| thcrit r | - | critical shields factor for MPM and Smart/Jäggi formula (default=0.05) |

| Input | Unit | Description |
|--|-------------------|---|
| repose r | - | tangens of angle of repose of bank material (default=1.0) |
| density r | kg/m ³ | density of the bed material (default=2650 kg/m ³) |
| porosity r | - | porosity of the bed material (default=0.30) |
| formula 'name' | - | sediment transport formula to be used: <ul style="list-style-type: none"> • mpm = Meyer-Peter/Müller formula. • smart&jaeppi = Smart/Jäggi formula • parker78 = Parker formula for uniform grain size |
| rock_thcrit r | - | critical shields factor for transport over bedrock (default=0.01) |
| rock_factor r | - | factor to account for transport over bedrock (default=1.8) |
| mpm_factor r | - | factor used in transport formula of Meyer-Peter/Müller (default=8.0) |
| mixture 'name' 0.2 0. 25. 1. | cm | grain size distribution of sediment mixture where the the grain size [cm] and the cumulative probability (sediment finer) are given in the 1 st and 2 nd column. Note: The last value in the 1 st column must be 1.0. |

>>compute

to define parameters for unsteady flow computation

| | | |
|---------------|---|---|
| start r | h | start time of the simulation (default=0) |
| end r | h | time where simulation will end (default=100h) |
| cfl r | - | limiting CFL number to estimate size of time step (default=0.6) |
| frequency i | - | refresh rate of display output (default=100). |
| batch_mode | | runs the model in batch_mode, i.e. starts the computation, stores the results on the specified file, and terminates |
| plot_interval | h | interval to store sediment output on file sed.out (default= 8760) |
| num_threads i | - | Maximum number of threads for computation (default = 1). Speeds up calculation on systems with multi-core (multi-thread) CPU's. |

>>create_model

main keyword for the specification of model-specific parameters


| | | |
|-------------|--------|--|
| name 'name' | string | name of model (displayed on model output) |
| type '2D' | | type of model: <ul style="list-style-type: none"> • '1D' for one-dimensional flow calculations (river branch) • '2D' for two-dimensional flow calculations |

>>init

definition of the calculation domain

| | | |
|-------------|--------|--|
| mesh 'name' | string | reads the mesh geometry from files. Supported formats are: .node created by program TRIANGLE (file name without suffix!) .2dm created by program SMS (splits 4-noded elements to triangles) .tin triangulated irregular network format (used in ems-i programs) |
|-------------|--------|--|


| Input | Unit | Description |
|-------------------------|--------|--|
| binary 'name' | string | reads mesh geometry and initial conditions (flow depths, flow and bedlevels) from a binary file created by a previous run. <i>Note: Use either mesh or binary (not both) for the definition of the mesh geometry.</i> |
| at r | h | time level r of initial condition to be read from the binary file. |
| bedlevel =+-<> 'name' | | reads a mesh geometry from files created by program triangle. Depending on the operator it changes the level of the model bed. Example: bedlevel = 'new_dam.1' will read the bedlevel values from the mesh defined by the files new_dam.1.node and new_dam.1.ele. Possible operators are: = new bedlevel + lift the bedlevel - lower the bedlevel < maximum bedlevel > minimum bedlevel <i>Note: Must be used in combination with mesh (not binary).</i> |
| waterlevel =+-<> 'name' | | Same as option bedlevel (see row above) but operates on waterlevels. <i>Note: Must be defined after definition of bedlevels.</i> |
| >>polygon | | used to define values that hold in a domain defined by a closed polygon. Example: <pre>>>polygon !keyword n 0.02 !keyword for Manning's n value 100. 150. !list of vertices of polygon 320. 165. 240. 190. 105. 155.</pre> |
| bedlevel =+-<> r | m | to modify the bedlevels by a value r using an operator (see keyword >>init/bedlevel for meaning of operators). Example: bedlevel > 321.0 ! minimum bed level is 321 m 100. 150. 320. 165. 240. 190. 105. 155. |
| flowdepth r | m | flow depth at start time (initial condition) |
| ks r | m | equivalent sand roughness diameter |
| kst r | SI | Manning-Strickler value |
| n r | SI | Manning's n value |
| vegetation r | 1/m | vegetation factor given by the formula $vegetation = \frac{d}{a^2} c_w$ with d = diameter of vegetation elements [m], a = distance between elements [m] and c_w = drag coefficient (range 0.8 – 1.5). Can be used to account for drift wood effects (see >>drift). |


| Input | Unit | Description |
|---|-------------------|---|
| waterlevel r | m | water level at start time (initial condition) |
| bridge r | m | level of a bridge (Z_{bridge}) to account for backwater effects. It accounts for the acceleration of the flow due to the reduced flow section. It does <u>not</u> account for external forces on the bridge plate or other effects such as flow contraction (gated flows). |
|  | | |
| no_seam x1 y1 x2 y2 . . | - | closed polygon to define cells that do not connect to 1D-branches. |
| >>boundary | | used to define (time-dependent) boundary conditions at the model boundaries that are inside a polygon. The polygon covers all the edges of the calculation mesh where the boundary condition holds. It must not match exactly with the edges. The steps are: (1) Define a boundary type (e.g. an inflow) (2) Define the location where the boundary holds by a closed polygon using the keyword location . |
| inflow r | m ³ /s | defines an inflow discharge (** for time dependent inflow). The discharge is distributed among the boundary cells assuming uniform flow conditions given the slope of the energy head (uniform_slope, default = 0.001). |
| uniform_slope r | - | |
| critical | | defines an outflow boundary with a critical flow regime (no backwater effect) |
| slope r | - | defines an outflow boundary with r = energy slope |
| waterlevel r | m | defines an outflow boundary with r = water level |
| stage-discharge z1 q1 z2 q2 . . | | defines an stage-discharge outflow boundary with z=water level [m] and q=discharge [m ³ /s] |

Example (i) Given an inflow of 100 m³/s at a boundary where the mean slope is approx. 0.5%. The boundary condition reads

```
>>boundary
inflow 100
uniform_slope 0.005
location
100. 150.
100. 150.
200. 200.
100. 200.
```

| Input | Unit | Description |
|--------------------------|---------------------|---|
| | | <p>Example (ii) At an outflow boundary the water level rises from 96.5 m to 98.0 m during half an hour and returns to the old value after one hour. The outflow has to be stored on the file 'waterlevel.out' for further usage. The boundary condition reads</p> <pre>>>boundary waterlevel ** > 'waterlevel.out' 0.0 96.5 0.5 98.0 1.0 96.5 location 900. 150. 930. 155. 950. 240. 910. 260.</pre> |
| >>structure | | to define internal sources and structures (culverts, weirs, controls) |
| point_source x y q | m,m ³ /s | defines an internal source with x,y = co-ordinates of source position and q = constant discharge. For unsteady inflows write ** and add a timetable of the inflows. |
| culvert x1 y1 x2 y2 | m | defines the flow through a circular or rectangular culvert with (x1,y1) and (x2,y2) = co-ordinates of the in- and outlet. The module accounts for in- or outlet controlled flow condition. It is assumed that the vertical level of the in- and outlet corresponds to the bed level of the adjacent grid cell. |
| | | <p>Example:</p> <pre>culvert x1 y1 x2 y2 > 'name'</pre> <p>writes the discharge through the culvert to file 'name'</p> |
| diameter r | m | diameter of circular culvert (default= 1 m) |
| width r | m | width of rectangular culvert |
| height r | m | height of rectangular culvert. |
| n r | SI | Manning's n value of culvert [default= 0.02]. |
| kst r | SI | Strickler value of culvert [default= 50]. |
| inlet_loss r | - | inlet loss coefficient that depends on shape of culvert inlet. Values usually vary between 0.2 (rounded entrance) and 0.7 (sharp crested entrance)(default= 0.5). |
| maximum r | m ³ /s | maximum discharge through culvert (** for time table). |

| Input | Unit | Description |
|-------------------------------------|-------|--|
| weir zw cw | | <p>flow over weir with zw = level of weir crest [m] and cw = poleni coefficient (default = 0.58). Flow over weir can be written to a file by adding > 'filename'. Example:</p> <pre>weir 433.65 0.64 > 'weirflow.out'</pre> <p>location ...</p> <p>Time_dependent weir levels are defined in a table where the time [h] and the weir_crest are given in the first and second column, respectively. Example:</p> <pre>weir ** 0.64 0.0 433.65 0.8 434.15 1.5 433.80</pre> <p>location ...</p> |
| gate zg cg | m,- | <p>flow through gate with zg = level of the lower end of the sluice gate (see figure) and cg = contraction coefficient (default = 0.62). Flow through gate can be written to a file by adding > 'filename'. Example:</p> <pre>gate 426.45 0.80 > 'gateflow.out'</pre> <p>location ...</p> <p>Time_dependent gate openings are defined in a table where the time [h] and the opening are given in the first and second column, respectively. Example:</p> <pre>gate ** 0.80 0.0 426.45 0.1 425.00</pre> <p>location ...</p>  |
| control_gauge x y z | m,m,m | <p>water level control with reference level z [m] at position defined by co-ordinates x,y. Control values can be written to a file by adding > 'filename'.</p> |
| control_param dt u | s,m/s | <p>free parameters for level control (fictitious weir):</p> <ul style="list-style-type: none"> ● dt = time lag [s] between adjustment of weir level ● u = velocity [m/s] of weir level adjustment |
| control_init zw | m | <p>initial level of (fictitious weir) crest (default: control level)</p> <p>Example:</p> <pre>control_gauge 29.5 94.8 433.65 >'control.out'</pre> <pre>control_param 300. 0.002</pre> <pre>control_init 433.20</pre> <p>location ...</p> |
| location x1 y1 x2 y2 . . . | | <p>location of weir/gate/control section defined as a set of vertices with x- and y- coordinates in first and second column, respectively.</p> |

| Input | Unit | Description |
|--|-------------------|--|
| pile x y d cD | | accounts for drag forces on a pile (pier) at location x,y with d= diameter [m], cD = drag coefficient (default = 1.0 for circular shape). |
| cross-pile z d cD xA yA xB yB | | accounts for drag forces on a horizontal element that spans from A to B with z = level [m], d = diameter [m], cD = drag coefficient (default = 1.0 for circular shape). |
| | |  |
| | | Hint: Cross-piles can be used to model drag forces due to bridge plates. |
| >>variation | | is used to define variation of model parameters during simulation |
| bedlevel =+-<> ** t1 r1 t2 r2 . . | m | definition of time-dependent values of bed level using an operator (see keyword >>init/bedlevel for meaning of operators). |
| rock_level = ** t1 r1 t2 r2 . . | m | definition of time-dependent values of rock level (for bed load calculation). |
| location . . | | co-ordinates of polygon vertices to define location of variation. |
| deposit r1 r2 r3 r4 r5 | | adds depth of flow to the bed level (to account for deposition of debris flow) at time r1 [h]. Simultaneous the global (rheological) parameters can be changed: kst (r2), yield_stress (r3), friction_slope (r4), and bingham_viscosity (r5) |
| >>drift | | is used to define effects of coarse woody debris (CWD). The shape of the CWD is a cylindrical log of which the diameter is D and the length is $L = 10 \cdot D$. |
| float r | - | relative flow depth h/D that logs become mobile (default = 0.5) |
| logdiameter r1 r2 | m | minimum and maximum diameter of logs. |
| load r | m ³ /h | volume of CWD per hour that is given into the model. For variable values replace r by ** and add a table with the time [h] and the corresponding load [m ³ /h] in the 1 st and 2 nd column. |
| location x1 y1 x2 y2 . . | | location of CWD source (feeder) defined as a polygon |
| >>sediment | | the following data is related to bed load calculations |
| dmo r | cm | reads mean diameter of grains (valid for whole domain) |
| dmo 'name' | string | reads variable grain size as a mesh created by program triangle ("name.node" and "name.ele"). To be used for uniform grain size calculation (unit [cm]). |

| Input | Unit | Description |
|---|-------------|--|
| inflow r location x1 y1 x2 y2 . . | kg/s | sediment inflow (r=** for unsteady inflows). location of sediment inflow (feeder) given as a closed polygon |
| rock_depth r x1 y1 x2 y2 . . | m | defines a rock level below the initial bed level in a closed polygon defined by the co-ordinates x,y |

>>output

is used to define the output from the model

prefix 'name' string results are written to file **name.res** (binary for review) and **name.out** (input reading)

interval r h interval between time steps to be stored on result file (default = 1 h)

hydrograph 'item' x y > 'filename'

writes nodal value at location (x,y) as a hydrograph table to file.
Accepted items are:

| | |
|--------------|-----------------------------------|
| 'bedlevel' | bed level [m s. l.] |
| 'waterlevel' | water level [m s. l.] |
| 'depth' | flow depth [m] |
| 'flow' | Specific flow [m ² /s] |
| 'velocity' | flow velocity [m/s] |

write 'item' at r > 'filename'

write nodal values at time r [h] to file. See table above for accepted items.

flow > 'fname'
x1 y1
x2 y2
. .

writes total flow across a section to file 'fname'. The section must be defined as a polygon with vertices x,y. The location of edges can be displayed with Show/Mesh option. Note that the direction of the flow is not considered..

sediment > 'fname'
x1 y1
x2 y2
. .

writes sediment flow across a section to file 'fname'. The section must be defined as a polygon with vertices x,y. The location of edges can be displayed with Show/Mesh option. Note that the direction of the flow is not considered..

>>

denotes the end of the input. Any further input is ignored.

2 History

Version 3.0 (2016-)

- unlimited model size (allocatable arrays)
- parallel processing (multi-thread CPU's)
- initial weir levels (for waterlevel controls)

Version 2.3 (2014-15)

- >>variation for time-dependent rocklevels
- adjustment of stress terms for debris flow calculations

Version 2.2 (2011-2013)

- module to account for coarse woody debris
- bingham like friction law for debris flow calculations.
- >>variation for time-dependent values (replaces >>breach)

Version 2.1 (2009-2011)

- accepts mesh geometries in .2dm format created by SMS (Surface water Modeling System) and .tin format (see [description](#))
- serial linking of 2d and 1d models
- cross-piles to account for hydraulic resistance of horizontal structures such as bridges
- export of results in (ESRI) shape format
- simplified input for flow over weirs and gated flows
- modeling of water level controls (e.g. hydro power stations)
- modeling debris flow with two-parameter approach (turbulent & yield)

Version 2.0 (2006-2009)

- considering multiple models (1D and 2D)
- accepts project files to change river bed topography
- new flow option

Version 1.0 - 1.3 (1999-2005)

- stage-discharge outflow boundary
- development of breaches during simulation time
- export of hydrograph tables
- variable bed_evolution values and boundary conditions
- bed armouring (2-grain-size model)
- automatic generation of animated output (movies)
- perspective views with shading
- modelling of precipitation/evaporation
- energy losses due to vegetation
- multiple (independent) meshes
- mobile bed module
- improved interpolation of bed level for narrow dams
- improved graphic routines
- output of multiple time steps on same result file
- logarithmic friction law
- backwater effects due to bridges
- time dependent boundary conditions
- distributed inflow discharge assuming uniform flow conditions
- culvert flow to connect model domains
- weir and gated flow over cell edges
- friction values (kst or n) defined with closed polygons (mesh independent)
- wetting and drying of cells